


# Configurer Luminair avec le Connect-One

1




2

Cliquer sur l'icône de statut et sélectionner le menu Art-Net.



3

Ensuite, sélectionner le sous-menu « Node ».



4


Désélectionner « Broadcast ». Puis, entrer « 192.168.1.1 » comme adresse IP.

Il est aussi possible de sélectionner le nœud « Connect-One » si disponible. La configuration réseau se fera automatiquement.



# Configurer Luminair avec le Connect-One

1




2

Cliquer sur l'icône de statut et sélectionner le menu Art-Net.



3

Ensuite, sélectionner le sous-menu « Node ».



4


Désélectionner « Broadcast ». Puis, entrer « 192.168.1.1 » comme adresse IP.

Il est aussi possible de sélectionner le nœud « Connect-One » si disponible. La configuration réseau se fera automatiquement.



# How to configure Luminair with your Connect-One

**1**




In your Wi-Fi settings, select the Access Point named « Connect-One ... ».

The screenshot shows the iPhone Settings app with the Wi-Fi section expanded. A blue circle highlights the 'Connect-One 1014' network, which is marked with a checkmark and 'Security Recommendation'. A blue arrow points from the text box to this network.

**2**


Click on the status icon and select the Art-Net menu.



The screenshot shows the Luminair app interface. At the top right, a status icon (a gear with a lightning bolt) is circled in blue. A blue arrow points from the text box to this icon. Below it, the 'Art-Net' menu option is also circled in blue. The background shows a dimmed view of the lighting control interface with various scene buttons.

**3**

Then, select the « Node » sub-menu.




The screenshot shows the 'Art-Net' settings menu. A blue circle highlights the 'Node' option, which is currently set to 'None'. A blue arrow points from the text box to this option. Other options like 'Enabled', 'Subnet', and 'Universe' are visible.

**4**

First, disable « Broadcast ». Then, enter « 192.168.1.1 » as IP Address.


You can also select the « Connect-One » node if available. It will automatically configure the network for you.



The screenshot shows the 'Broadcast' settings menu. A blue circle highlights the 'Broadcast' toggle switch, which is currently turned off. A blue arrow points from the text box to this toggle. Below it, the 'IP Address' field is set to '192.168.1.1' and is also circled in blue. The background shows a dimmed view of the lighting control interface.

# How to configure Luminair with your Connect-One


**1**



In your Wi-Fi settings, select the Access Point named « Connect-One ... ».

**2**

Click on the status icon and select the Art-Net menu.



**3**

Then, select the « Node » sub-menu.



**4**

First, disable « Broadcast ». Then, enter « 192.168.1.1 » as IP Address.

You can also select the « Connect-One » node if available. It will automatically configure the network for you.

